



NOTE: Place a wire jumper between "SEL" pins 2 and 3 when the 2000S Antenna Selector is not used.

